

## beam scan in y by accelerator controls

scan coordinates for ybeamscan2-11-07 rad 2e-5.txt


y (mm)

burt scan ybeamscan2-11-07\_rad\_2e-5.txt







## active collimator opposite y-wedge asymmetry



## consistency of active collimator response with active target rate






#### inner wedges 5-th order poly fit:

p0	=	-2.61809
p1	=	8.37568
p2	=	-1.30637
p3	=	1.47959
p4	=	0.615187
p5	=	31.0245


#### outer wedges 5-th order poly fit:


p0	=	-2.68086
p1	=	13.9037
p2	=	-0.712466
p3	=	15.3233
p4	=	-0.758043
p5	=	4.94836


## beam scan in x by accelerator controls




## active collimator opposite x-wedge asymmetry









### consistency of active collimator response with active target rate



# beam collimator scan in x by accelerator motor controls



# active collimator opposite x-wedge asymmetry



active collimator response is much more smooth and symmetric with collimator motor scans!

## active collimator opposite x-wedge asymmetry vs Xbeam-Xcol


### fit: x-wedge asymmetry → x of beam in collimator coordinates

inner x-wedges outer x-wedg		wedges	ges	
p0	= -1.54026	р0	= -1.6961	
p1	= 6.30612	p1	= 11.3452	
p2	= 0.301719	p2	= 0.632244	
р3	= 8.42805	р3	= 46.9961	
p4	= -0.736145	p4	= -2.63319	
p5	= 10.2121	p5	= -423.482	
p6	= -5.50989	p6	= 7.26192	
p7	= -97.3332	p7	= 1595.65	
p8	= -4.79739	p8	= 10.9569	
p9	= 243.495	p9	= -1807.57	

Rule of thumb during initial running was that the beam is centered when the beam center of gravity on the profiler is at (-1, -4) mm.

## now check fit using opposite y-wedge calibration against y\_bpu

collimator scan beam\_0018.asc.root



#### 2D calibration is needed

- 1. dA/dy depends on x
- good central region ±3mm where x,y approx. decoupled
- 3. excellent agreement between inner / outer wedges.

### Why the tilt?

- 1. active collimator is tilted?
- beam ellipse is tilted?
- 3. profiler is sensitive to beam components (eg. X-rays) not seen by active collimator?